



## **Marlite FRP, Envue FRP, & Symmetrix w/ Sani-Coat**

### ***Overview***

For best results, engage in a regular cleaning schedule to avoid dirt build-up. As a general rule, any mild cleaner applied with a sponge or soft brush is safe and effective. Avoid using any cleaner or stain remover considered abrasive or containing chlorinated hydrocarbons or aromatic hydrocarbons.

### ***Cleaning Agents***

The following cleaning agents have been tested and approved. Be sure to test any cleaning agent not appearing on this list in a small, inconspicuous area first.

- Murphy's Oil Soap
- Lysol
- Mr. Clean
- Formula 409 Multi-purpose cleaner
- Fantastik Multi-purpose cleaner
- Simple Green Multi-purpose cleaner

### ***Application Method***

Apply the cleaning agent with a sponge or soft brush, working it across the surface in a scrubbing or circular motion. Rinse thoroughly using cold water.

### ***For Graffiti and Other Stubborn Stains***

If the aforementioned cleaning agents fail to remove graffiti or other stubborn stains, the following more powerful agents have been tested and approved for use with caution:

Misty Vandalism Mark Remover  
Censor Vandalism Mark Remover

*Please note:* For Envue FRP and Symmetrix FRP with Sani-coat, apply a minimal amount of cleaner and completely wipe off with a smooth rag within ten seconds of application. Failure to do so will remove the Sani-coat surface. Do not disturb the panel face for thirty minutes after wiping off the cleaning agent. The Sani-coat surface will temporarily soften and return to its original strength after the thirty minute time period. The quick wipe method is not necessary for use on traditional Marlite smooth or textured FRP panels.

These powerful cleaning agents are flammable. Be sure to take proper precautions when using these or any flammable materials.